






Update #15 + #17




Fittings for 15 eller / or 17



F1 x 4 (For 15)
F1 x 3 (For 17)
(6005250)



F3 x 4 (For 15)
F3 x 3 (For 17)
(6005100)




F5 x 1
(4000582)



F2 x 8 (For 15)
F2 x 6 (For 17)
(6700503)



F4 x 8 (For 15)
F4 x 6 (For 17)
(6603215)






F6 x 2
(6706423)






F7 x 2
(6200210)




3



4



5



- ↻ Loosen
Løsne
- ↻ Tighten
Spænde
- ↻ ↻ Adjust
Juster
- ↔ ↕ Move
Flyt

